IPI 100 Series Installation Instructions

IPI 100 Series Overview

The Extron IPI 100 series are one- (IPI 101) or four- (IPI 104) button IP intercom modules that are used to create an easy-to-use, two-way IP Intercom® system. They facilitate room-to-help-desk or room-to-room communication within a building, campus, or a wider area, as long as the intercoms are connected to the same network. The IPI 101 can communicate with one other location; the IPI 104 can communicate with four other locations.

Refer to www.extron.com for the complete user manual and installation complete user manual and installation instructions before connecting the product to the power source.

Each room in the Intercom system requires either an IPI 100 series, with an MLC 226 IP MediaLink® Controller or an IPI 200 series module. **The IPI 100 module must be connected to the the MLC 226 IP controller**. The IPI 100 must be no more than 100 feet (30 meters) from the controller; a 12 inch (30.5 cm) cable is provided. Only one IP address and network drop are needed because the IPI 100 uses the same network drop as the MLC 226 IP Controller. Consult with your IT department to ensure that IP addresses have been correctly allocated.

Also on the network, there must be at least one PC that is running the IP Intercom HelpDesk™ software to coordinate the intercom system. The IP Intercom HelpDesk software, which is provided with the IPI 100 Series intercoms, allows any PC on the network equipped with a microphone and speaker, or a headset, to become a help desk station. The software is also available for free download from the Extron website (www.extron.com).

The IP Intercom HelpDesk software offers the following features:


- Works with IPI 100 Series IP Intercom stations to enable two-way communication with a classroom and ensure rapid problem resolution.
- Sets up, accesses, and manages audio for IP Intercom modules.
- Pages one room or a group of rooms.
- Forwards calls automatically from a help desk that is busy to one that is available.

Network and IT administrators should use information from the following white papers, which can be found on the Extron website (www.extron.com), to ensure optimal network configuration and compatibility for the IP Intercom system:

- "IP Intercom Network Impact Statement"
- "IP Intercom Best Installation Practices"

Extron recommends that the IP Intercoms and the HelpDesk be on the same LAN with a static IP address and not be separated by a firewall. If the IP addresses are on different subnets, it is best to set up a dedicated VLAN. If a firewall is required, the following ports need to be open: UDP port 3121 (audio traffic), TCP telnet port 23 (control and status), UDP port 3122 (inter-helpdesk communication), and UDP ports 1230 and 1231 (auto discovery).

Typical IP Intercom Application



68-1170-50 **Rev A** 04 09

IPI 100 Series Installation Instructions, cont'd

Installation

Before installing your IPI 100, read the following publications, which can be found on the Extron website (www.extron.com):


- "IPI 100 Series and IPI 200 Series User's Manual"
- "IP Intercom System Frequently Asked Questions"

WARNING


Installation and service must be performed by authorized personnel only. These products must be used with UL approved grounded electrical boxes.

The front panel of the IPI 104 is shown at right. The front panel for the IPI 101 is the same, except there is only one button. The rear panels for both units are identical and are shown in the illustration below.

- Determine which rooms will have IP Intercoms and PC HelpDesks and where, in each room, they will be located. Ensure there is a network connection for each intercom and each HelpDesk PC.
- 2. Connect the IPI to the MLC 226 IP controller, using the included 12 inch (30.5 cm) network cable.
- 3. Cable the MLC 226 IP to other devices:



IPI 104 AAP Front Panel



- Connect the LAN port to the local network, using a standard network cable with an RJ-45 connector.
- If desired, cable the rear panel audio connector for local audio output.
- Cable other devices (control modules, SCP, and/or IR emitters) to the MLC as needed (for more information, see the MLC 226 IP User's Manual, which is available on the Extron website (www.extron.com).
- 4. Install the IPI 100 unit and the MLC 226 IP into the wall box(es) or furniture.
- Ensure the HelpDesk PC(s) are connected to the network, and power on the MLC(s) and PC(s).
- **6.** Configure the MLC(s) as described in the *MLC 226 IP User's Manual* and the Global Configurator Help File, which are available on the Extron website (www.extron.com).
- 7. Install the Extron IP Intercom HelpDesk software, which is on the disk that shipped with the unit and is also available for download from the Extron website (www.extron.com).
- 8. Use the IP Intercom HelpDesk software to configure all intercom units in the system. Full instructions can be found in the IPI 100 Series and IPI 200 Series User's Manual and also in the software's Help File.

When the front panel button(s) light amber, the unit is correctly installed and configured. If the button(s) light red the unit has not been correctly configured and you should check the *IPI 100 Series and IPI 200 Series User's Manual* or the software's Help File.

- 1	Extron USA - West	Extron USA - East	Extron Europe	Extron Asia	Extron Japan	Extron China	Extron Middle East
	Headquarters +800.633.9876	+800.633.9876 Inside USA / Canada Only	+800.3987.6673 Inside Europe Only	+800.7339.8766 Inside Asia Only	+81.3.3511.7655 +81.3.3511.7656 FAX	+400.883.1568 Inside China Only	+971.4.2991800 +971.4.2991880 FAX
	Inside USA / Canada Only +1.714.491.1500 +1.714.491.1517 FAX	+1.919.863.1794 +1.919.863.1797 FAX	+31.33.453.4040 +31.33.453.4050 FAX	+65.6383.4400 +65.6383.4664 FAX		+86.21.3760.1568 +86.21.3760.1566 FAX	